


# DOMINATOR<sup>®</sup>

## Select

Sectional Door Opener



# Contents

|                                                    |    |                                              |    |
|----------------------------------------------------|----|----------------------------------------------|----|
| 1. Important Safety Warnings!                      | 3  | 15. Coding a Transmitter                     | 16 |
| <b>Installation Instructions</b>                   |    | 15.1 Storing the Transmitter Code            | 16 |
| 2. Before you Begin                                | 5  | 15.2 Remotely Coding Transmitters            | 16 |
| 3. Tools Required                                  | 5  | 15.3 Erasing All Transmitter Codes           | 17 |
| 4. Kit Contents                                    | 6  | 15.4 Vacation Mode                           | 17 |
| 5. Position                                        | 6  | 15.5 Installing the Wall Mounted Transmitter | 17 |
| 6. Fit the Opener                                  | 7  | <b>Home Owner Instructions</b>               |    |
| 7. Bracket Position                                | 7  | 16. Opener Safety & Security                 | 18 |
| 8. Perforated Angle                                | 8  | 16.1 Your Door CAN NOT be used when:         | 18 |
| 9. Mounting Brackets and Arms                      | 8  | 16.2 Your Door CAN be used when:             | 18 |
| 10. Optional Safety Beam Kit                       | 9  | 16.3 To Disengage the Opener:                | 18 |
| 10.1 Assemble the Mounting Bracket                 | 9  | 16.4 To Re-engage the Opener:                | 18 |
| 10.2 Mounting the Bracket                          | 9  | 17. Operating your Opener                    | 18 |
| 10.3 Wiring the 2 Wire PE Beam                     | 9  | 18. User Operating Controls                  | 19 |
| 10.4 Aligning the Transmitter and Receiver         | 9  | 19. Troubleshooting                          | 20 |
| 11. Specifications                                 | 10 | 20. After Installation Care                  | 22 |
| 12. Setting Limits                                 | 11 | 20.1 Service Checklist                       | 22 |
| 12.1 Set the Limit Positions & adjust drive speed: | 11 | 20.2 Battery Replacement                     | 23 |
| 12.2 Clearing the Door Limit Positions             | 12 | 20.3 Battery Disposal                        | 23 |
| 12.3 Re-profiling the Door                         | 12 | 20.4 Warranty                                | 23 |
| 12.4 Controller memory reset                       | 12 | 21. Appendix                                 | 24 |
| 13. Safety Testing                                 | 13 | A - Status Indication during Operating Mode. | 24 |
| 13.1 Test the Close Cycle                          | 13 | B - Adjustment Mode Instructions             | 25 |
| 13.2 Testing the Open Cycle                        | 13 | C - Adjusting Force Margins                  | 26 |
| 13.3 Test the Manual Door Operation                | 13 | D - Battery Functions                        | 26 |
| 14. Auto-Close                                     | 14 | E - Setting the PET mode position            | 26 |
| 14.1 Auto-Close                                    | 14 | F - Setting Limits via Transmitter           | 27 |
| 14.2 Terminal Block                                | 15 | G - Setting up Tilt Door                     | 28 |
| 14.3 Connecting or Disconnecting Accessories       | 15 |                                              |    |

## WARNING! IMPORTANT SAFETY INSTRUCTIONS

### FOLLOW ALL INSTRUCTIONS SINCE INCORRECT INSTALLATION CAN LEAD TO SEVERE INJURY.

- before installing the drive, remove all unnecessary ropes or chains and disable any equipment, such as locks, not needed for powered operation;
- before installing the drive, check that the door is in good mechanical condition, correctly balanced and opens and closes properly;
- install the actuating member for the manual release at a height less than 1,8 m;
- install any fixed control at a height of at least 1,5 m and within sight of the door but away from moving parts;
- permanently fix the labels warning against entrapment in a prominent place or near any fixed controls;
- permanently fix the label concerning the manual release adjacent to its actuating member;
- after installation, ensure that the mechanism is properly adjusted and that the drive reverses when the door contacts a 40 mm high object placed on the floor.
- necessary information for the safe handling of a drive weighing more than 20 kg. This information shall describe how to use the handling means, such as hooks and ropes;
- the drive must not be used with a door incorporating a wicket door (unless the drive cannot be operated with the wicket door open);
- after installation, ensure that parts of the door do not extend over public footpaths or roads.
- vertical doors and gates need an anti-drop feature or device;
- information if a hazardous part of the drive is intended to be installed at a height of at least 2.5 m above floor level or other access level;
- except for horizontally moving pedestrian doors, ensure that entrapment due to the opening movement of the driven part is avoided

# 1. Installation Safety Warnings!

This automatic garage door opener is designed and tested to offer safe service provided it is installed and operated in strict accordance with the following safety warnings. Failure to comply with the following instructions may result in death, serious personal injury or property damage.



## WARNING!

- The door may operate unexpectedly, therefore do not allow anything to stay in the path of the door.
- When operating the manual release while the door is open, the door may fall rapidly due to weak or broken springs, or due to being improperly balanced.
- The drive must not be used with a door incorporating a wicket door, unless the drive cannot be operated with the wicket door open.
- The drive is intended to be installed at least 2.5m above the floor.
- Do not disengage the opener to manual operation with children/persons or any objects including motor vehicles within the doorway.
- If the door is closing and is unable to re-open when obstructed, discontinue use. Do not use a door with faulty obstruction sensing
- When using auto close mode, a Photo Electric beam must be fitted correctly and tested for operation at regular intervals. Extreme caution is recommended when using auto close mode. All safety rules must be followed.



## ELECTROCUTION!

- Place opener in protected area so that it does not get wet.
- Do not spray with water .
- Disconnect the power cord from mains power before making any repairs or removing covers. Only experienced service personnel should remove covers from the opener.
- If the power supply cord is damaged, it must be replaced by an Automatic Technology service agent or suitably qualified person.
- Connect the opener to a properly earthed general purpose 240V mains power outlet installed by a qualified electrical contractor.



## CAUTION:

Emergency Access

Muscular strain

Fall from ladder

Crush injury from  
unsecured door

Garage Door

Entanglement

Entrapment under  
operating door

- If garage has no pedestrian entrance door, an emergency access device should be installed. This accessory allows manual operation of the garage door from outside in case of power failure.
- Practice correct lifting techniques (carton weighs approx 5.7kgs)
- Practice correct lifting techniques when required to lift the door as per installation instructions.
- Ensure ladder is the correct type for job.
- Ensure ladder is on flat firm ground that will take the weight without the legs sinking.
- Ensure user has 3 points of contact while on ladder.
- Place a 2 metre exclusion zone around area under the door while it is unsecured.
- Follow the installation instructions
- Examine the door installation, in particular, springs and mountings for signs of wear, damage and imbalance.
- The garage door must be well balanced. Sticking or binding doors must be repaired by a qualified garage door installer prior to installation of the opener.
- Remove or disengage all garage door locks and mechanisms prior to installation of the opener.
- Never plug in and operate opener prior to installation.
- Keep hands and loose clothing clear of door and guides at all times.
- DO NOT operate the opener unless the garage door is in full view and free from objects such as cars and children/people. Make sure that the door has finished moving before entering or leaving the garage
- In order for the opener to sense an object obstructing the door way, some force must be exerted on the object. As a result the object, door and/or person may suffer minor damage or injury.
- Ensure the garage door is in good working order by undertaking regular servicing.
- Install the optional wall transmitter in a location where the garage door is visible, but out of the reach of children at a height of at least 1.5m.
- Photo Electric beams must be installed if the closing force at the bottom edge of the door exceeds 400N (40kg)

# DOMINATOR®

# 1. Home Owner Safety Warnings!

This automatic garage door opener is designed and tested to offer safe service provided it is installed and operated in strict accordance with the following safety warnings. Failure to comply with the following instructions may result in death, serious personal injury or property damage.

## WARNING! IMPORTANT SAFETY INSTRUCTIONS

IT IS IMPORTANT FOR THE SAFETY OF PERSONS TO FOLLOW ALL INSTRUCTIONS.

### SAVE THESE INSTRUCTIONS



#### WARNING!

- Automatic Door - the door may operate unexpectedly, therefore do not allow anything to stay in the path of the door.
- Details on how to use manual release. When operating the manual release while the door is open, the door may fall rapidly due to weak or broken springs, or due to being improperly balanced.
- **DO NOT** disengage the opener to manual operation with children/persons or any objects including motor vehicles within the doorway.
- If the door is closing and does not re-open when obstructed, discontinue use. **DO NOT** use a door with faulty obstruction sensing.
- Frequently examine the installation, in particular check cables, springs and mountings for signs of wear, damage or imbalance. **DO NOT** use if repair or adjustment is needed since fault in the installation or an incorrectly balanced door may cause injury..



#### ELECTROCUTION!

- Place opener in protected area so that it does not get wet.
- **DO NOT** spray with water .
- **DO NOT** open the protective covers.
- **DO NOT** operate opener if cable is damaged. It must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- Disconnect the supply(s) when cleaning or other maintenance is being carried out..



#### DO NOT DO IT YOURSELF

- Keep the garage door balanced. Sticking or binding doors must be repaired. Garage doors, door springs, brackets and their hardware are under extreme tension and can cause serious personal injury. **DO NOT** attempt any garage door adjustment. **DO NOT** use if repair or adjustment is needed. Call for a professional garage door service.



#### BATTERY WARNING!

- This product contains a lithium button/coin cell battery in the transmitters. If a new or used lithium button/coin cell battery is swallowed or enters the body, it can cause severe internal burns and can lead to **DEATH** in as little as 2 hours. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the battery and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, **SEEK IMMEDIATE MEDICAL ATTENTION**.



#### CAUTION:

Emergency access

Entrapment under operating door

Fall from Ladder

Entanglement in or laceration from moving door

- If your garage has no pedestrian entrance door, an emergency access device should be installed. This accessory allows manual operation of the garage door from outside in case of power failure.
- Watch the moving door and keep people away until the door is completely opened or closed. **DO NOT** operate door when persons are near the door.
- **DO NOT** allow children to play with door controls or transmitters. Keep remote controls away from children.
- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Children being supervised not to play with the appliance.
- Regularly conduct Open and Close cycle testing.
- Each month check that the drive reverses when the door contacts a 40mm high object placed on the floor. Adjust if necessary and recheck since an incorrect adjustment may present a hazard.
- Ensure the garage door is in good working order by undertaking regular servicing.
- Wall transmitters should be installed in a location where the garage door is visible, but out of the reach of children at a height of at least 1.5m.
- Install Safety Beams (recommended).
- Ensure ladder is the correct type for the job.
- Ensure ladder is on flat ground.
- Ensure user has 3 points of contact while on ladder.
- Keep hands and loose clothing clear of door and guides at all times.
- Keep hands clear of moving door as sharp edges can cause cuts or lacerations.

## 2. Before you Begin

### 2.1 Examine the conditions in the garage:

#### a. Look at the ceiling:

- Is it plastered? The opener is mounted to a perforated angle which **MUST** be securely fastened to a structural support. You will need to locate the structural beams in the ceiling which are generally 400mm apart.
- does it have exposed beams? The opener is mounted to a perforated angle which must be securely fastened to a structural support like the exposed beams. You may need to install a 40mm thick board (not supplied) between structural supports.

#### b. Look at the wall above the garage door.

- Is it brick? The wall bracket **MUST** be securely fastened to the wall with suitable screws and ensure it does not move.
- Is it timber? The wall bracket **MUST** be securely fastened to a structural support. You may need to install a 40mm thick board (not supplied) between structural supports to fasten the wall bracket to.


### 2.2 Test the following before commencing installation:

- The door **MUST BE** in good operating condition.
- Manually move the door up and down, the door should move freely without binding or sticking. When the door is fully closed it should raise itself by 10cm off the floor. Retension door if necessary.
- The maximum force required to move the door should not exceed 20kg.
- Lift the door to about halfway. When released, the door should stay in place.




#### DO NOT DO IT YOURSELF:


If any of the above door requirements are not met, **DO NOT** attempt to fix yourself. Please contact a garage door professional. (P) 0800 366 462



## 3. Tools Required



4. Kit Contents



1.

1 x DSO drive unit
2.

1 x Bent arm door attachment
3.

1 x Wall Transmitter
4.

2 x Transmitters
- PLUS
5.


1 x Track Hardware Kit
6.

1 x Pre-Assembled track

5. Position

The Opener:



- a. MUST BE installed in a dry position, protected from weather.
- b. REQUIRES properly earthed 3 pin single phase power on the ceiling within an arms length of the opener.
- c. Requires a MINIMUM HEADROOM of 57mm between the highest point of the door's travel and the ceiling.
- d. Use the diagram below as a reference when completing the installation.



## 6. Fit the Opener

### 6.1 Secure C-Rail to Opener:

- Remove the Opener from the box, taking care of antenna (if fitted).
- Locate and insert the shaft of drive unit (1) into the C-Rail's sprocket.
- Fix the two track brackets (5a) with four (4) M4 x 8 screws (5k) supplied in accessory pack.
- Place drive unit back in packing box for protection.



## 7. Bracket Position


### 7.1 Wall Bracket Position:

- Determine the centre of the door and mark this point with a line on the wall above.
- Raise the door and find the highest point of travel of the first (top) door panel.



**WARNING!** The Opener must be securely fastened to structural supports, otherwise opener failure may ensue causing serious personal injury and / or property damage.


- Using step ladder and a level, transfer this height to the wall above the door and mark a line 60mm above it, across the centre line.



**DO NOT DO IT YOURSELF:** If sufficient structural support can not be found, contact a door professional for installation.


### 7.2 Mounting the Wall Bracket:

- Draw two lines extending 21.5mm from each side of the centre point.
- Centre the wall bracket (5e) over the intersection of these two lines. Mark centres for at least two holes and ensure it is into a solid mounting point.
- Drill holes in the wall with an appropriate bit.
- Secure to the wall using:
  - IF CONCRETE OR BRICK:  
8mm (5/6") loxins/dynabolts.
  - IF TIMBER:  
wood screw #20 or similar (min. 50mm).



### 7.3 Attach the Track to the Wall Bracket


- Leave the drive unit in its packing box on the floor for protection and lift the other end of the C-Rail.
- Attach the pre-assembled track (6) to the wall bracket (5e) with the 90mm long pin (5h) and secure with the supplied pin snap (5f).




## 8. Perforated Angle (Not supplied)

### 8.1 Attach Perforated Angle or equivalent

- Measure across the ceiling from the centre point 3175mm (+/- 150mm) to find a supporting beam.
- Create a perforated angle which best suits your site. Use a hack saw to cut the L shape metal strips. Secure the perforated angle to a supporting beam using diagrams shown below.
- Raise the drive unit to the ceiling mounted perforated angle and secure with M8x20mm screws (not supplied). Strips should not extend more than 18mm below centre of drive unit mounting holes.
- To prevent moisture on the C-rail running into the powerhead it is recommended a strip of silicon sealant is placed across the top of the C-rail just before the opener.



**Ceiling Beams that run towards the door requires:**  
1 x perforated L shape metal strip and  
2 x shorter perforate L shape metal drop down strips.



**Ceiling Beams that run parallel to the door requires:**  
2 x perforated L shape metal strips and  
2 x shorter perforate L shape metal drop down strips.

**WARNING!** The perforated angle **MUST** be securely fastened to a structural support. The installer **MUST** select and use fasteners appropriate to the material into which they are being fixed.


**tip** Straighten the antenna on the opener, by pulling straight down to ensure optimal reception.

## 9. Mounting Brackets and Arms

### 9.1 Mounting the Door Bracket:

- The door bracket locator (5d) is placed over the door bracket (5c), on the door's centre line one-third down the top panel and mounted using M6 or equivalent screws (not supplied).
- STEEL DOORS ONLY:** Bracket can be welded in place.


**NOTE:** If in doubt about the door's strength, reinforcement may be added to the door's frame where necessary. Door damage may occur if the bracket is installed on a panel with insufficient strength. The opener's warranty does not cover damage caused to the door and/or door panels.



### 9.2 Attaching the Arms

- Assemble the bent arm (2) (connecting to the door) to the right side of the straight arm (5b) with bolts (5g) and nuts (5j). Connect the straight arm (5b) to the shuttle with a clevis pin (5i) and a pin snap (5f). Always use both bent and straight arms.
- Connect the assembled arm to the bracket with clevis pin (5i) and pin snap (5f). The angle "A" must be more than 10°.

**tip** For J-Type doors: Refer to Appendix G for attaching arms



## 10. Optional Safety Beam Kit



**WARNING!** The Opener must be fitted with Safety Beams if:


- the closing force at the bottom edge of the door exceeds 400N (40kg) and/or;
- the opener has a smart device fitted to operate the door, when not in line-of-sight.



**CAUTION!** The Safety Beam must be installed and connected before the travel limits are set.

### 10.1 Assemble the Mounting Bracket

- Attach the PE 2000TS Bracket (1) to the Safety Beam Transmitter (TX) using four (4) M3 x 5 Taptite screws (4).
- Connect the mounting bracket (3) to the adjustment bracket (2) with two (2) of the M5 x 10 Pan Head Screws (5).
- Repeat steps (a) and (b) to assemble the Safety Beam Receiver (RX).
- Mount the receiver on the side of the doorway in shade and the transmitter on the other side in line with the receiver. The mounting surface should be rigid. Affix with a minimum of four (4) screws (not supplied).




### 10.2 Mounting the Bracket

The transmitter and receiver need to be placed in line of sight, with the beam 100mm above the ground level (as per AS/NZS 60335-2-95:2020). This can be achieved by ensuring the bottom of the receiver and transmitter are 65mm above ground level. They should also be placed as close as possible to the door opening with the receiver (RX) in shade and the transmitter (TX) in sun or shade.

Assembling Flush Mounting Kit (for minimum sideroom applications)

- Attached the transmitter (TX) and receiver (RX) to the two (2) PEB4-W1 Bracket (1) with the four (4) M3 x 8 Taptite screws "P" (4).
- Ensure to take note of the ATA recommendation in step (d) above and fix the TX and RX to the wall or rigid surface using the two (2) 6.9 x 25 plastic wall plugs (if wall) and two (2) M6 x 25 self tapping screws.




### 10.3 Wiring the 2 Wire PE Beam

- Ensure to disconnect power to the opener before opening cover to connect the 2 Wire PE as per wiring diagram.
- Refit cover when finished.

### 10.4 Aligning the Transmitter and Receiver

- Power up the opener with the safety beams connected.
- The LED on the receiver and transmitter will light up and flicker, indicating communication is being established between each unit and the base station. This can take up to 60secs. Lights will:
  - Stay on solid = When communication is established but limits are not set.
  - Go out = When communication is established and limits are set.
- The opener beam alignment feature can be used to align beams via the beeper and main light as a guide;
  - bright = aligned
  - dull and Beeper sound = not aligned or blocked.

When the beams are aligned, continue with Section 12 Setting Limits.



# 11. Specifications

| Technical Specifications                                                                                    | Select DSO-1V3                                               |
|-------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
| Rated voltage range:                                                                                        | 230V - 240V.                                                 |
| Rated frequency:                                                                                            | 50Hz                                                         |
| Rated power input:                                                                                          | 195W                                                         |
| Door opening:<br>Maximum Door Area:<br>Maximum Door Weight:                                                 | 16.5m <sup>2</sup><br>140kg*                                 |
| Door must be well balanced and able to be operated by hand, as per warranty conditions and AS/NZS 4505:2012 |                                                              |
| Minimum headroom                                                                                            | 57mm                                                         |
| Rated Operating Time                                                                                        | 4 mins                                                       |
| Rated Temp                                                                                                  | +5°C to +40°C                                                |
| Short Term Peak force:                                                                                      | 700N                                                         |
| Door travel speed (mm/sec)                                                                                  | 180mm                                                        |
| Rated load                                                                                                  | 400N                                                         |
| Maximum lifting under spring tension                                                                        | 200N (20kg)                                                  |
| Receiver type                                                                                               | Multi-frequency UHF FM                                       |
| Receiver code storage capacity                                                                              | 64 X 4-button Transmitters                                   |
| Transmitter battery                                                                                         | CR2032 (3 Volts)                                             |
| Courtesy light                                                                                              | LED (Light Emitting Diodes)                                  |
| Network connectivity                                                                                        | Network ready<br>(requires optional smart phone control kit) |

\* Gross door weight, including all fittings

Note: During the open and close cycles, intermittent operations may occur in areas which experience very strong winds. The strong wind puts extra pressure on the door and tracks which may in turn intermittently trigger the safety obstruction detection system.



## 12. Setting Limits

### 12.1 Set the Limit Positions and adjust drive speed:



When setting the Close limit, ensure the position is when the door makes first contact with the ground. Alternatively for the Open limit the position should be at the height of the garage opening.

| STEP ONE                                                      | STEP TWO                                     |
|---------------------------------------------------------------|----------------------------------------------|
| <br>Switch power on<br><br>BLUE LED will flash & gear LED lit | OR<br>To move the door to the halfway point. |

| CLOSE LIMIT POSITION                                                   |                                                                                                                               |
|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| <b>STEP ONE</b><br><b>HOLD</b><br>Take note of the speed as door moves | <b>STEP TWO</b><br>If Close speed not suitable, release button, THEN<br><br><b>HOLD</b> Each press changes speed as per table |

| MAIN LIGHT & BEEPER | SPEED MODE     |
|---------------------|----------------|
| x 3 + 3 x           | FAST (Default) |
| x 2 + 2 x           | MEDIUM         |
| x 1 + 1 x           | SLOW           |

| STEP THREE                                                                  | STEP FOUR                                                                                                        |
|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| <br><b>RELEASE</b> <b>HOLD</b><br>When at desired speed Press to close door | <br>When door near close, single presses inch door<br>CLOSE limit should be when rubber strip touches the ground |



**WARNING!** In setting the close limit position, do not force the door into the floor with excessive force, as this can interfere with the ease of operation of the manual release mechanism.

| STEP FIVE          |                          |                     |
|--------------------|--------------------------|---------------------|
| If door overshoots |                          |                     |
| <b>Press</b>       | <b>Press to position</b> | <b>Press to set</b> |



**CAUTION!** Limit setup is not available when running on battery backup



Refer to Appendix F for setting limits via a transmitter. **NOTE** - Speed of the opener can not be adjusted when using this method.

**NOTE:** The drive speed is set to the fastest setting by default. This may not be suitable for larger doors or for single piece doors. For tilt doors (J-Type only), please refer to **Appendix G** for initial setup.



Refer to Appendix B & C for adjustments to margins and Appendix E to set the PET Mode position

| OPEN LIMIT POSITION                                                    |                                                                                                                              |
|------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| <b>STEP ONE</b><br><b>HOLD</b><br>Take note of the speed as door moves | <b>STEP TWO</b><br>If Open speed not suitable, RELEASE button, THEN<br><br><b>HOLD</b> Each press changes speed as per table |

| MAIN LIGHT & BEEPER | SPEED MODE     |
|---------------------|----------------|
| x 3 + 3 x           | FAST (Default) |
| x 2 + 2 x           | MEDIUM         |
| x 1 + 1 x           | SLOW           |

| STEP THREE                                                                 | STEP FOUR                                                                                                  |
|----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| <br><b>RELEASE</b> <b>HOLD</b><br>When at desired speed Press to open door | <br>When door near open, single presses inch door<br>OPEN limit should be the height of the garage opening |



**WARNING!** The door will automatically close, open and close again after the next step. Ensure that nothing is in the door's path.

| STEP FIVE                                                       |                          |                     |
|-----------------------------------------------------------------|--------------------------|---------------------|
| If door overshoots                                              |                          |                     |
| <b>Press</b>                                                    | <b>Press to position</b> | <b>Press to set</b> |
| Door will open & close to calculate safety obstruction settings |                          |                     |

NOTE: If unhappy with the speed or travel limit setting, restart this procedure by resetting the door limit positions as per below first.

12.2 Clearing the Door Limit Positions

STEP ONE

Remove controls cover

Press repeatedly

till gear LED lit

STEP TWO

**HOLD for 10 sec**

Release when light stops flashing

STEP THREE



The BLUE LED flashes continuously to show limits cleared

NOTE: No action taken within 30 secs, the opener returns to original settings.

SET Close & Open limits

12.3 Re-profiling the Door

 Re-profiling is a simple way of re-learning the travel characteristics of a previously setup Limit Switch travel. Re-profiling is used when travel characteristic change due to mechanical adjustments.

To initiate a re-profile: LIMITS must already be set.

STEP ONE


Remove controls cover

Press repeatedly

till gear LED lit

STEP TWO

**HOLD for 2 secs**

Door will open and close

STEP THREE

   **OFF** 

Press to exit

Then refit controls cover

12.4 Controller memory reset

To clear the controller:

 If limits are already set, clear limits first by following Clearing the door limit positions and then follow below.

STEP ONE

When in limit setting mode



The BLUE LED flashes continuously to show limits clear

STEP TWO

**HOLD for 10 sec**

Release

This will cause all control memory to be set to factory defaults EXCLUDING: transmitters, history log and cycle counters.

## 13. Safety Testing

### 13.1 Test the Close Cycle

- Press the OPEN button  or transmitter button to open the door (If the door starts closing, press the transmitter button to stop the door, then press transmitter again to open).
- Place a piece of timber approximately 40mm high on the floor directly under the door.
- Press the transmitter button to close door.
- The door should strike the object and re-open.
- Remove the timber.



**WARNING!** If the door is closing and is unable to re-open when obstructed, discontinue use. Do not use a door with faulty obstruction sensing.

### 13.2 Testing the Open Cycle

- Press the CLOSE button  or transmitter button to close the door.
- Press the transmitter button again to open the door.
- When the door reaches approximately half way, firmly grab the door's bottom rail - the door should stop.

If the door does not reverse readily when closing, or stop when opening, put the door into manual by pulling down on the manual release string to disengage the motor and contact 13 62 63 for support.


### 13.3 Test the Manual Door Operation

A poorly maintained door could cause fatal / serious injuries or damage to property:

- Frequently examine the door, particularly the cables, springs and mountings for signs of wear, damage or imbalance. **DO NOT USE** if repair or adjustment is needed since a fault in the installation or an incorrectly balanced door may cause injury.
- Fasteners: Check all screws, nuts and bolts to ensure they are secure.
- Spring Tension: It is natural for springs to lose tension. Should the door become hard to operate or completely inoperative, contact a door professional.
- Guide Tracks: Clean the internal sections of the guide tracks every 3 - 6 months with a cloth dampened with mineral turps or methylated spirits.
- Periodically disengage the opener and manually operate the door. The door must be smooth to operate by hand. The force required on the bottom rail should not exceed 20kg.



**CAUTION:** Take care when completing a safety test. Failure to follow this warning can result in serious personal injury and/or property damage.



**WARNING!** If the door fails these tests, put the opener into manual mode, only operate the door by hand and call for service.



**WARNING!** Safety beams must be installed if the closing force at the bottom edge of the door exceeds 400N (40kg).

# 14. Auto-Close

## 14.1 Auto-Close

Auto-Close mode is a function that automatically closes the door after a pre-set time. Safety beams must be installed in order to run the Auto-Close function. There are two types of Auto-Close available:

- i. Standard auto-close - the door will Auto-Close after a programmed time. In this mode the timer starts to countdown as soon as the door is fully open. This function is useful in case the safety beam does not get triggered.
- ii. Safety Beam triggered auto-close - the door will auto-close after a programmed time. In this mode the timer starts counting down only when the safety beam is triggered. ie car leaving the garage.

**WARNING! It is compulsory to have Safety Beams installed when using Auto-Close mode.**

STEP ONE

Remove controls cover





Press repeatedly





till gear LED flashing

STEP TWO



Press repeatedly





until gear LED flashes  
x 2 PE Auto  
x 3 Std Auto

STEP THREE



Press to enter parameter

Default setting for Auto-Close is OFF.



Parameter

| Value options = Indicated by brightness of main light                                                                                                                                                                                                       |    |     |       |       |       |       |        |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----|-----|-------|-------|-------|-------|--------|
|    |    |     |       |       |       |       |        |
|                                                                                                                                                                                                                                                             |    | 1   | 2     | 3     | 4     | 5     | 6      |
| PE AUTO-CLOSE                                                                                                                                                                                                                                               | x2 | OFF | 15sec | 30sec | 60sec | 90sec | -      |
| AUTO-CLOSE                                                                                                                                                                                                                                                  | x3 | OFF | 15sec | 30sec | 60sec | 90sec | 120sec |

STEP FOUR



Press to move through options as per table





Press to save

OR




Press to leave unchanged

DOMINATOR®

14.2 Terminal Block

Wired accessory items can be connected to the terminal block **J4**. Terminal connections from top down are as follows:

- a. **+35V** (Auxillary)
- b. **AUX** (Auxillary)
- c. **SB** (Safety Beam input, mandatory);
- d. **GND** (Common ground for accessories and Safety Beam);
- e. **GND** (Common ground)
- f. **OSC** (Open/Stop/Close trigger)



14.3 Connecting or Disconnecting Accessories

The opener can hold up to 4 accessories. For example Secure;

- Auto-Lock
- Wireless PE Beams
- Smart Hub



If an Auto-lock and Wireless PE Beams are both installed ensure that the channels on the base stations on each device are different. The channel on the base station can be changed by sliding the switch in either direction

STEP ONE

Remove controls cover

Press repeatedly

till gear LED lit

STEP TWO

HOLD for 2 secs

till 3 beeps are heard

STEP THREE

For PE Beams

Alignment Mode is entered. Ensure Alignment.

Then replace controls cover

OFF

Re-registering is required every time an accessory is removed.

# 15. Coding a Transmitter

## 15.1 Storing the Transmitter Code



The opener can only be operated from remote controllers that have been programmed into its memory. Up to 64 remotes can be programmed.

**STEP ONE**



Switch power on and remove controls cover

**STEP TWO**



Press repeatedly



till remote LED lit

**STEP THREE**



**HOLD**

Opener flashes & beeps



**HOLD for 3 sec**  
**RELEASE**  
**HOLD for 3 sec**

Release both buttons

**STEP FOUR**



Then refit controls cover

**STEP FIVE**



Press to test

NOTE: To code other transmitter functions, at STEP THREE refer to below table of buttons to press.

| TRANSMITTER FUNCTION  | BUTTON                                                                              |                                                                                     |                                                                                     |
|-----------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|                       |  |  |  |
| Open / Stop / Close   | HOLD                                                                                |                                                                                     |                                                                                     |
| PET (Pedestrian) Mode |                                                                                     | HOLD                                                                                |                                                                                     |
| Open                  |                                                                                     |                                                                                     | HOLD                                                                                |
| Light                 | HOLD                                                                                | HOLD                                                                                |                                                                                     |
| Vacation Mode         | HOLD                                                                                |                                                                                     | HOLD                                                                                |
| Aux Output            |                                                                                     | HOLD                                                                                | HOLD                                                                                |

\* The button coded for open only function can close the door if you hold the button for 4 seconds, when the door is fully open..

NOTE: The opener will flash and beep during coding, refer to below table for status indication..

| MAIN LIGHT & BEEPER                                                                                                                                                                           | TRANSMITTER STATUS     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|
|  ON + 2 x             | Button added           |
|  OFF + 2 x            | Button removed         |
|  x 2, then OFF + 2 x  | Remote control deleted |
|  x 4, then OFF + 4 x  | Memory full            |

## 15.2 Remotely Coding Transmitters



Remotely coding works when you have a pre-coded remote control and are in range of the opener.

**STEP ONE**



Take a pre-coded remote and press the button to duplicate

**STEP TWO**



Use a pen, **HOLD for 2 sec**



the middle button through the coding hole

**STEP THREE**

Opener flashes & beeps



**HOLD for 3 sec**  
**RELEASE**  
**HOLD for 3 sec**  
**RELEASE**

Take new remote

**STEP FOUR**

Opener stops flashing & beeping



Press to test



Remote code set is disabled when:

- powered by battery backup
- the service indicator is active
- when the door is indicating that it was prevented from closing by a P.E beam being blocked

15.3 Erasing All Transmitter Codes

**STEP ONE**

Remove controls cover

**STEP TWO**

 Press repeatedly  till remote LED lit

**STEP THREE**

   **HOLD for 10 sec** Release when flashing and beeping stops

**STEP FOUR**

Follow Section 15.1 to store new transmitter codes

15.4 Vacation Mode

**STEP ONE**

Remove controls cover

**STEP TWO**

 Press repeatedly  till remote LED lit

**STEP THREE**

 +   **HOLD** Opener flashes & beeps **HOLD for 3 sec RELEASE** **HOLD for 3 sec** Release all buttons

**STEP FOUR**

Then refit controls cover

**STEP FIVE**

Turn on  **HOLD for 4 sec RELEASE** Turn off  Press, then try another remote

15.5 Installing the Wall Mounted Transmitter

**STEP ONE**

Remove controls cover

 Press repeatedly  till remote LED lit


**STEP TWO**

 **HOLD** Opener flashes & beeps  **HOLD for 3 sec RELEASE** **HOLD for 3 sec** Release both buttons

**STEP THREE**

Then refit controls cover

**STEP FOUR**

Mount in view of door, away from children & at least 1.5m above floor. 

## 16. Opener Safety & Security

### 16.1 Your Door CAN NOT be used by the opener when:

- There is a locking device installed.
- There is a power failure.


### 16.2 Your Door CAN be used when:

- There is an emergency, by disengaging the opener.
- There is a power failure, by disengaging the opener.

### 16.3 To Disengage the Opener:



It is recommended to disengage the door with the door in the closed position.




**CAUTION:** When the opener is manually disengaged, the door is no longer locked. To lock the door manually, re-engage the opener after the door is closed.



**WARNING!** When operating the manual release (while the door is open) the door may fall rapidly due to weak or broken springs, or due to being improperly balanced.

Do not disengage the opener to manual operation with children/ persons or any objects including motor vehicles within the doorway.

### 16.4 To Re-engage the Opener:




**CAUTION:** Do not use the string handle as a mechanism to open the door. Failure to comply may cause serious injury.

## 17. Operating your Opener

### 17.1 To Operate the opener:


- Press the programmed transmitter button until your door begins to move (usually 2 seconds). Make sure you can see the door when you use the transmitter.
- If you are in a vehicle you should aim the transmitter through your windscreen as shown.
- Check that the door is fully open or closed before you drive in or away.
- If you press the transmitter whilst the door is moving the door will stop. The next press of the transmitter will move the door in the opposite direction.



**DOMINATOR®**

## 18. User Operating Controls

| Button                             | Function                                                                                                                                 |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| 1. DOWN ARROW (Blue)               | Closes the door                                                                                                                          |
| 2. DOWN ARROW LED (Blue)           | Illuminates when the door is closed and flashes when the door is obstructed on close or stopped.                                         |
| 3. STOP (Red)                      | Stops the door                                                                                                                           |
| 4. UP ARROW (Green)                | Opens the door                                                                                                                           |
| 5. UP ARROW LED (Green)            | Illuminates when the door is open and flashes when the door is open with the auto-close timer running, obstructed on opening or stopped. |
| 6. MODE (Yellow)                   | Enables Load Diagnostics Mode                                                                                                            |
| 7. MODE STATUS LED (Yellow)        | Illuminates when in Diagnostics Mode                                                                                                     |
| 8. REMOTE CONTROL STATUS LED (Red) | Flashes on remote lockout and flickers on remote control activity                                                                        |
| 9. ADJUSTMENT LED (Yellow)         | Flashes a certain number of times depending on the parameter being changed.                                                              |



# 19. Troubleshooting

| Symptom                                                | Possible cause                                                                                                                     | Remedy                                                                                                                                           |
|--------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| The opener does not work from the transmitter          | Garage door in poor condition e.g. springs may be broken                                                                           | Check the door's operation                                                                                                                       |
|                                                        | The opener does not have power                                                                                                     | Plug a device of similar voltage (e.g. a hairdryer) into the power point and check that it is OK                                                 |
|                                                        | The battery in the transmitter is flat                                                                                             | Replace the battery                                                                                                                              |
|                                                        | The opener has turned on "Vacation Mode"                                                                                           | Turn off "Vacation Mode" (Section 15)                                                                                                            |
|                                                        | The transmitter button is not programmed to operate the door.                                                                      | Code in the transmitter                                                                                                                          |
| One transmitter works but the other/s do not           | Faulty transmitter                                                                                                                 | Replace transmitter                                                                                                                              |
|                                                        | Flat battery                                                                                                                       | Replace battery                                                                                                                                  |
| The chain / belt moves but the door remains stationary | The opener is disengaged                                                                                                           | Re-engage the opener                                                                                                                             |
| Motor is running but chain / belt is not moving        | Damage motor assembly                                                                                                              | Contact your dealer for support.                                                                                                                 |
| The transmitter range varies or is restricted          | Variations are normal depending on conditions e.g. temperature or external interference                                            | Make sure you can see the door when you use the transmitter.                                                                                     |
|                                                        | The battery life is exhausted                                                                                                      | Check the battery status by pressing a button (flashing or no light, battery need changing)                                                      |
|                                                        | Position of the transmitter in the motor vehicle                                                                                   | Aim the transmitter through the windscreen.                                                                                                      |
| The Courtesy light does not work                       | LED has failed                                                                                                                     | Change LED.                                                                                                                                      |
| The door reverses for no apparent reason               | This may occur occasionally from environmental conditions such as areas that are windy, dusty or have extreme temperature changes. | Ensure the door runs smoothly before increasing the force pressure.                                                                              |
|                                                        | If Safety beams are installed they may be partially obstructed.                                                                    | Ensure the beam path is not obstructed. Check the Alignment.                                                                                     |
| Door will not close                                    | Safety Beam not working                                                                                                            | To access safety close mode, hold the transmitter button to close for 6 seconds and continue to hold while the door closes.<br>Check Safety Beam |
|                                                        | Safety Beam battery flat                                                                                                           |                                                                                                                                                  |
| Auto Close not working                                 | Safety Beam or wiring faulty                                                                                                       | Repair Safety Beam or replace wiring.<br>Re-align optics. See Safety Beam instructions.                                                          |
| The CLOSE (Blue) LED is flashing                       | Limits are not set                                                                                                                 | Set Up Limits (Section 12).                                                                                                                      |

# 19.Troubleshooting

## Main Light = Service / Warning Indicator:

Requirements for a service and user warnings are indicated after operation by the main light repeatably flashing OFF a number of times followed by a pause. When the alert is first triggered the beeper will also sound The below table identifies the issues and remedies.

| Flashes                                                                                | Issue                                                    | Remedy                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------|----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  x 2   | PE is preventing door from moving                        | Clear away any obstructions. Test Door. If unable to move the door and suspect beam is faulty, enter Safety Beam Emergency Close by pressing and holding a pre-coded button on transmitter for more than five seconds and the door will start closing. |
|  x 3   | Wireless LOCK battery is low                             | Change LOCK battery                                                                                                                                                                                                                                    |
|  x 4   | Wireless PE battery is low                               | Change PE Battery                                                                                                                                                                                                                                      |
|  x 5   | Wireless LOCK is not unlocked and preventing door moving | Check LOCK, test by pressing emergency release button on the lock and then test door operation.                                                                                                                                                        |
|  x 6   | Maintenance is due after pre-set number of cycles.       | Contact dealer to arrange service.                                                                                                                                                                                                                     |
|  x 7   | Backup battery is faulty                                 | Contact 0800 366 462 within New Zealand for assistance                                                                                                                                                                                                 |
|  x 8  | Door has hit an obstruction                              | Clear away any obstructions and test door opens/ closes correctly. (If door is damaged, contact your door professional)                                                                                                                                |
|  x 9 | Motor has overloaded or stalled                          | Check the doors operation by disengaging the motor and ensuring the door runs smoothly. If necessary make door adjustments or contact your door professional.                                                                                          |

## Main Light = FAULT Status Indicator (when MODE is on):

When MODE is ON, light flashes indicated number of times. When first triggered, the beeper will sound the indicated number of beeps. Attempting to operate the door will result in the beeps being heard again. The below table identifies the issues and remedies.

| Flashes                                                                                          | FAULT                                                                                                                                                                                                                  |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  x 2<br>or x 3 | Failed while profiling door after setting limits. Can be caused by any event which cause door to stop. For example P.E beam being blocked on closing, hit an obstruction, etc. Also can occur if battery is activated. |
|  x 4<br>or x 5 | Position Fault                                                                                                                                                                                                         |
|  x 6           | Motor driving in wrong direction                                                                                                                                                                                       |
|  x 7           | Memory fault                                                                                                                                                                                                           |
|  x 8           | Motor current sensor fault.                                                                                                                                                                                            |

**If You Need a Service Call** - If the opener needs a service please call the dealer who installed the garage door opener (their contact details are usually on a sticker on the back of your garage door). For product assistance contact 0800 366 462 within New Zealand.

**BEFORE CALLING** you should have the following information to assist in providing the appropriate service:

1. Has anything happened since the opener last operated OK, e.g. a storm, a jolt to the door etc.?
2. What is the current light status on the opener?
3. Manually disengage the door (Section 18). How easy is it to manually open and close the door?
4. What model is the opener? (Model no. information is located at the rear of the opener)
5. Who installed the opener? (Dealer details should be on a sticker on the back of your garage door)
6. When was it installed? (If known)

# 20. After Installation Care

## 20.1 Service Checklist

Preventative servicing of your garage door and opener, is just as important as servicing your car. Much like the engine of your car, your garage door is made up of numerous moving parts designed to lift and lower your door safely and efficiently.

Ongoing preventative servicing ensures that your door continues to function within factory specifications, greatly reduces the risk of failure and repair bills down the track and ensures you maintain your Warranty.



Run the Safety Testing procedures MONTHLY in Section 13 to ensure garage door is fit for use.



**WARNING!** Failure to maintain your your garage door voids the warranty on your garage door opener.



**DO NOT DO IT YOURSELF:**  
Door adjustments should only be carried out by experienced persons, as this function can be dangerous if not performed under strict safety procedures.

### TECHNICIAN CHECKLIST

- 1. Lubrication of the critical moving parts including chain drive, tracks, wheels or cable drum.
- 2. Tightening of door mounting points along with door bolts, screws, cables and connectors.
- 3. Adjustment of spring tension to limit 'spring fatigue'.
- 4. Adjustment of opener travel limits and force margin to ensure the door opens and closes to specification.
- 5. Assessment and adjustment of safety components and accessories including safety beams, Auto-Lock and Safe Lock (if installed)
- 6. Assessment of the door alignment and the diagnosis of irregular operation remedies.
- 7. Record Cycle count at each service to establish next date of service (as per table)

|                                                               | SERVICE 1<br>(12 months after installation<br>or 3,000 cycles) |       | SERVICE 2<br>(3 years after installation) |       | SERVICE 3<br>(5 years after installation) |       |
|---------------------------------------------------------------|----------------------------------------------------------------|-------|-------------------------------------------|-------|-------------------------------------------|-------|
| DATE:                                                         |                                                                |       |                                           |       |                                           |       |
| BUSINESS NAME:                                                |                                                                |       |                                           |       |                                           |       |
| TECHNICIAN NAME:                                              |                                                                |       |                                           |       |                                           |       |
| PG3 COUNTERS                                                  | OPEN                                                           | CLOSE | OPEN                                      | CLOSE | OPEN                                      | CLOSE |
| STALLS                                                        |                                                                |       |                                           |       |                                           |       |
| OBSTRUCTIONS                                                  |                                                                |       |                                           |       |                                           |       |
| SENSOR FAULTS                                                 |                                                                |       |                                           |       |                                           |       |
| OVERLOADS / CUT-OUTS                                          |                                                                |       |                                           |       |                                           |       |
| WARRANTY CYCLES                                               |                                                                |       |                                           |       |                                           |       |
| FIRMWARE UPDATE AVAILABLE?<br>IF 'YES' PLEASE UPDATE FIRMWARE | YES                                                            | NO    | YES                                       | NO    | YES                                       | NO    |
| CURRENT FORCE MARGIN                                          |                                                                |       |                                           |       |                                           |       |
| TECHNICAL SIGNATURE:                                          |                                                                |       |                                           |       |                                           |       |

|                                                               | SERVICE 4<br>(7 years after installation) |       | SERVICE 5<br>(9 years after installation) |       |
|---------------------------------------------------------------|-------------------------------------------|-------|-------------------------------------------|-------|
| DATE:                                                         |                                           |       |                                           |       |
| BUSINESS NAME:                                                |                                           |       |                                           |       |
| TECHNICIAN NAME:                                              |                                           |       |                                           |       |
| PG3 COUNTERS                                                  | OPEN                                      | CLOSE | OPEN                                      | CLOSE |
| STALLS                                                        |                                           |       |                                           |       |
| OBSTRUCTIONS                                                  |                                           |       |                                           |       |
| SENSOR FAULTS                                                 |                                           |       |                                           |       |
| OVERLOADS / CUT-OUTS                                          |                                           |       |                                           |       |
| WARRANTY CYCLES                                               |                                           |       |                                           |       |
| FIRMWARE UPDATE AVAILABLE?<br>IF 'YES' PLEASE UPDATE FIRMWARE | YES                                       | NO    | YES                                       | NO    |
| CURRENT FORCE MARGIN                                          |                                           |       |                                           |       |
| TECHNICAL SIGNATURE:                                          |                                           |       |                                           |       |



# 20. After Installation Care

## 20.2 Battery Replacement

 **tip** Battery Type: 1 x CR2032.

**STEP ONE**



Check Light Status Table 


**HOLD**

| Light Status | Battery |
|--------------|---------|
| Solid        | OK      |
| Flashing     | Replace |
| No light     | Replace |




**WARNING!** The battery is hazardous and must be kept out of reach of children. The battery can cause severe or fatal injuries within 2 hours or less if swallowed or placed inside any part of the body. If you suspect the battery has been swallowed or placed inside any part of the body, **SEEK IMMEDIATE** medical attention.

**STEP TWO**



Use screwdriver to remove screw and open

**STEP THREE**



Use non-metallic object to push out.

## 20.3 Battery Disposal

When batteries reach the end of their usual life please follow the next simple steps for protecting the environment.



**WARNING!** The Battery shall be disposed of properly, including keeping them away from children. Even used batteries may cause injury.



**DO NOT** throw the batteries in municipal waste. This symbol of the crossed out wheeled bin indicates that the battery should not be placed in the municipal waste. Check your local regulations for appropriate disposal of the batteries.

Recycling all batteries will have other environmental and social benefits:

- Some batteries are less toxic but hazardous for other reasons. Lithium batteries can explode or catch fire in landfill, while button cells are dangerous if swallowed by children. Recycling offers a safe and environmentally responsible solution for end of life batteries.
- Battery recycling recovers non-renewable materials such as lead, cadmium, steel, zinc, manganese, cobalt, silver, plastics and rare earth elements.
- Removal of batteries and other hazardous household products from household waste facilitates the recovery of organic materials through alternative waste technologies such as composting. Batteries and heavy metals are known contaminants in compost.
- The community supports recycling because it reduces waste to landfill and achieves environmental benefits.



**WARNING!** Prior to disposal, recycling, or collection, all battery terminals must be securely insulated with a non conductive material to prevent any two batteries from short circuiting and generating heat during storage or transport. Battery terminals may be insulated with electrical tape; or batteries may be individually packaged in a non conductive material (e.g., plastic bag or original packaging).

## 20.4 Warranty

Full details of the warranty are available in your Owners Opener Handbook, from your nearest Dominator office or visit the Dominator Website [dominator.co.nz](http://dominator.co.nz).



# 21. Appendix

## A - Status Indication during Operating Mode.

| LEDs                      | Light Status                                                                      |                                                                                   |                                                                                   |                                                                                     | Indicates                         |
|---------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-----------------------------------|
|                           | BLUE                                                                              | GREEN                                                                             | YELLOW                                                                            | RED                                                                                 |                                   |
| DOOR OPEN AND CLOSED LEDS |  |  |                                                                                   |                                                                                     |                                   |
|                           |                                                                                   | solid                                                                             |                                                                                   |                                                                                     | Open                              |
|                           |                                                                                   | rapid flashing                                                                    |                                                                                   |                                                                                     | Open with Autoclose timer running |
|                           |                                                                                   | flashing                                                                          |                                                                                   |                                                                                     | Opening / Obstructed on Open      |
|                           | solid                                                                             |                                                                                   |                                                                                   |                                                                                     | Closed                            |
|                           | flashing                                                                          |                                                                                   |                                                                                   |                                                                                     | Closing / Obstructed on Close     |
|                           | flashing                                                                          | flashing                                                                          |                                                                                   |                                                                                     | Stopped                           |
|                           | solid                                                                             | solid                                                                             |                                                                                   |                                                                                     | Partial Open                      |
| MODE LED                  |                                                                                   |                                                                                   |  |                                                                                     |                                   |
|                           |                                                                                   |                                                                                   | flashing                                                                          |                                                                                     | Load Diagnostics mode             |
| REMOTE CONTROL STATUS LED |                                                                                   |                                                                                   |                                                                                   |  |                                   |
|                           |                                                                                   |                                                                                   |                                                                                   | flashing                                                                            | Remote lockout from vacation mode |
|                           |                                                                                   |                                                                                   |                                                                                   | rapid flashing                                                                      | Remote Control Activity           |

## B - Adjustment Mode Instructions

### STEP ONE

Remove controls cover



till gear LED starts flashing

### STEP TWO



OR



Observe the number of flashes to indicate the parameter.

Press to move through options as per table below



Press to enter parameter

|               |    | Value options = Indicated by brightness of main light |             |       |        |               |        |
|---------------|----|-------------------------------------------------------|-------------|-------|--------|---------------|--------|
|               |    |                                                       |             |       |        |               |        |
| Parameter     |    | 1                                                     | 2           | 3     | 4      | 5             | 6      |
| MARGIN        | x1 | <u>1.0A</u>                                           | 1.2A        | 1.4A  | 1.6A   | 2.0A          | -      |
| PE AUTO-CLOSE | x2 | <u>OFF</u>                                            | 15sec       | 30sec | 60sec  | 90sec         | -      |
| AUTO-CLOSE    | x3 | <u>OFF</u>                                            | 15sec       | 30sec | 60sec  | 90sec         | 120sec |
| LIGHT TIMER   | x4 | 30sec                                                 | 60sec       | 90sec | 120sec | <u>180sec</u> | 240sec |
| AUX OUTPUT    | x5 | Mimic light                                           | <u>1sec</u> | 30sec | 60sec  | 120sec        | 180sec |



**tip** When parameter edit mode is active, if any button other than MODE is pressed, then when MODE is pressed again, operating mode will be selected instead of the NETWORK adjustment mode.



**tip** **DEFAULT parameter (underlined)**

### STEP THREE

the remote LED is lit when editing active

### STEP FOUR

Use either button to scroll through

If no beep is heard, max or min setting is reached.



Pressing the MODE button when a parameter is being adjusted will load the default value.

### STEP FIVE



OR



Operating MODE is entered after 5 secs, unless a new adjustment is started or saved.



#### LIGHT TIMER

- Adjusts the time the main light will remain on after the door is operated or a remote control code set to the Light remote control function is used.

#### AUX OUTPUT

- Configures how the AUX Output operates. If configured for Mimic light mode then the AUX output will activate whenever the main light output is on.
- All other settings require either a remote control code set to the AUX function or the Phone App to be used to activate the output.
- The time settings option indicates how long the output will remain on when triggered. If the output is already on, then a 2nd trigger will turn the output off.
- The toggle On/Off setting does not use a timer and the output simply changes state on each trigger..

C - Adjusting Force Margins

The Safety Obstruction Force is calculated automatically during setup. Adjusting this is normally only necessitated by environmental conditions such as windy or dusty areas, and areas with extreme temperature changes.

**STEP ONE**

Remove controls cover

Press repeatedly

till gear LED flashing

**STEP TWO**

Press together

remote LED is on and gear LED flashing

**STEP THREE**

Press to increase

OR

Press to decrease

Light will dim or brighten

**STEP FOUR**

Press to save

Press to exit

Then refit controls cover

D - Battery Functions

- a. Holding the STOP button for 10secs when running from battery backup will shut the PCB down so as to reduce battery current consumption to a minimum.
- b. Holding the STOP button for 4secs when a battery is fitted and running from mains power will cause the controller to test the battery state to determine if it is disconnected / open circuit, missing, faulty or ready.

E - Setting the PET mode position

**STEP ONE**

HOLD

Close to desired position

**STEP TWO**

Remove controls cover

Press repeatedly

till gear LED lit

**STEP THREE**

Press to save

Opener will flash and beep

LED will light up

**STEP FOUR**

Refit controls cover

Press to exit

Proceed to Storing the transmitter Code to code a remote button to PET Mode

**tip** When activated, PET mode drives the door to a preset position from the close position, therefore allowing a pet or parcel to go under the door.

## F - Setting Limits via Transmitter



The SPEED setting on the opener CAN NOT be adjusted when setting limits via the transmitter. Follow section 12.1 to set limits and adjust speed.

### STEP ONE



Switch power on



BLUE LED will flash  
& gear LED lit

### STEP TWO

Remove controls cover



Press  
repeatedly

till remote  
LED lit

### STEP THREE



Then refit  
controls cover

**HOLD**

Opener  
flashes &  
beeps

**HOLD for 3 sec**

**RELEASE**

**HOLD for 3 sec**


Release both  
buttons

### CLOSE LIMIT POSITION

#### STEP ONE



**HOLD**  
to Close



Button 4 is factory coded  
to CLOSE function.

#### STEP TWO



When door near  
close, single  
presses inch door

CLOSE limit should be  
when rubber strip touches  
the ground



**WARNING!** In setting the close limit position, do not force the door into the floor with excessive force, as this can interfere with the ease of operation of the manual release mechanism.

### STEP THREE

If door overshoots



Press to set



Press to Open

Press to Close  
position


Button 2 is factory  
coded to SET function

### OPEN LIMIT POSITION

#### STEP ONE



**HOLD**  
to Open



Button 1 is factory coded  
to OPEN function.

#### STEP TWO



When door near  
open, single  
presses inch door

OPEN limit should be the  
height of the garage  
opening



**WARNING!** The door will automatically close. open and close again after the next step. Ensure that nothing is in the door's path.

### STEP THREE

If door overshoots





Press to Close

Press to Open  
position

Press to set

## G - Setting up Tilt Door

**! tip** If installing on a door with a bad wave action, lengthening the arm will assist in reducing this effect.



Prior to limit set up, the opener can be set to J-Type Tilt Profile. This process allows the opener to pre-set to J-Type settings where the limit is not greater than 1500mm.

**! tip** In JTYPE Mode the drive speed is reduced and cannot be adjusted.

## STEP ONE



Switch power on



BLUE LED will flash  
& gear LED lit

## STEP TWO

To activate JTYPE Mode



Press together and opener  
will beep TWICE

## STEP THREE

To return to Standard Mode



Press together and opener  
will beep ONCE

## STEP FOUR



OR



Proceed to Setting  
Close Limit position.

To move the door to the  
halfway point.

## Dominator Garage Doors &amp; Openers

46 Braeburn Drive, Hornby, Christchurch, New Zealand

Dominator Locations Nationwide

PH: 0800 DOMINATOR (366 462)

or visit: [dominator.co.nz/dealer-locations](http://dominator.co.nz/dealer-locations)

Prefixed trademarks are the property of B&D Door NZ Ltd. Dominator Garage Doors & Openers is a division of B&D Group Pty Ltd. ABN 25 010 473 971. © 2019 B&D Group Pty Ltd.

[dominator.co.nz](http://dominator.co.nz)

your representative is

**DOMINATOR**