

# Merlin Remote Coding Instructions



*Genuine 94335E*



*Genuine C940*



*Active CM842*

## Programming Your Remote Into the Motor

- 1 Press and hold the desired transmitter button
- 2 Press the orange (ir roller motor) or purple (if overhead opener) Learn button
- 3 Let go of the desired transmitter button
- 4 Test the operation of your new remote

## Clearing The Codes From Your Motor

- 1 Press and hold the Learn button for 10 seconds, or until the LED goes out
- 2 Test that your remote no longer operates the motor

Watch us on

