

SEIP Coding Instructions



Genuine TM60



Genuine SKR433-3



Genuine SKRJ433

Programming Your Remote Into the Motor

- 1 Depending on your motor's model, you may need to remove a screw to allow the hinged cover to open. Once open, locate the RED push button on the circuit board.
- 2 Press this button for 5 seconds, or until the LED begins to flash.
- 3 Press and hold any button on your new remote control for two seconds, or until the LED stops flashing.

Clearing The Codes From Your Motor

- 1 Push and hold the RED push button on the circuit board for ten seconds.
- 2 After three seconds the light will begin to blink and after ten seconds it will remain solid.
- 3 After the LED goes solid, release the button. Your remotes should now be deleted.