

Avanti Coding Instructions



Genuine Avanti



Compatible Avanti



Active Avanti

Programming Your Remote Into the Motor

- 1 Hinge open your courtesy light to expose the "Learn" button
- 2 Press the "Learn" button until the LED indicator grows solid. This is less than 2 seconds
- 3 Press and hold the desired remote button until the LED extinguishes
- 4 Press and hold the same remote button again, and the LED will rapidly flash.
- 5 Once the LED ceases flashing, test the operation of your new remote control!

Clearing The Codes From Your Motor

- 1 Hinge open your courtesy light to expose the "Learn" button
- 2 Press the "Learn" button until the LED indicator grows solid. This is less than 2 seconds
- 3 Press and hold the black "Run" button until the LED begins to rapidly flash
- 4 Once the LED stops flashing, test to ensure your remotes no longer operate the motor

Watch us on

