

B&D Billion Code Instructions



B&D 4335a



B&D PTX4 Black

Programming Your Remote Into the Motor

- 1 Press and hold the desired button on your remote control
- 2 Push and release the orange learn button found on your motor. The light will flash once.
- 3 Release the button on your remote control, and test the operation of your new remote!

Clearing The Codes From Your Motor

- 1 Push and hold the orange "Learn" button until the indicator light turns off
- 2 Test the operation of your remote to ensure it no longer activates your motor

Watch us on

