

Merlin E128M Coding Instructions



Genuine E128M



Genuine E138M

Programming Your Remote Into the Motor

- 1 Locate the Learn Button on your motor.
- 2 Press and hold the button on the remote control or wireless wall control you wish to use.
The LED indicator on the opener flashes continuously.
- 3 Press and immediately release the Learn button.
- 4 The opener light flashes or 2 clicks are heard when it has learnt the code
- 5 Test the operation of your new remote control

Clearing The Codes From Your Motor

- 1 Press and hold the Learn button for 6 seconds, or until the LED goes out
- 2 Test that your remote no longer operates the motor

Watch us on

