



National Garage
REMOTES & OPENERS

B&D CAD4 Remotes

Programming Guide



B&D 4335a



B&D PTX4 Black



Auto Openers B&D



Learn Button for B&D CAD4

Programming Your Remote Control

- 1 Press and hold the desired button on your remote control
- 2 Push and release the orange learn button found on your motor. the motor will flash once.
- 3 Release the button on your remote control and test the operation of your new remote!

Clearing The Codes From Your Motor

- 1 Push and hold the orange "Learn" button until the indicator light turns off
- 2 Test the operation of your remote to ensure it no longer activates your motor
 - Please note, this will clear every remote programmed into the motor

For technical support, see our website below.
Please have the model number of your remote control and garage / gate opener before calling.

www.ngro.com.au