


Gliderol TM390 Programming Guide





Note: Pressing the enter button for 5 seconds or more will erase all handset data from your operator - be careful not to press the enter key for longer than neccessary

Programming Your Remote Control

- 1 Press and hold the "Enter" button for two seconds to access the operator menu
- 2 Use the arrow keys to select the Learn option and press enter. The unit will beep 3x.
- 3 Press any button on the remote. The motor will beep once if successfull.
- 4 Allow three seconds for the unit to exit setup mode. Your remote will then be ready for operation!

Clearing The Codes From Your Motor

- 1 Press and hold the enter button for 5 seconds
- 2 Test that your remote no longer operates the motor

For technical support, see our website below. Please have the model number of your remote control and garage / gate opener before calling.